



Deck Lid Quick Release Pins Instructions

1. Use a narrow punch and drive the stock hinge pin out of the hinge assembly, going from the inside to the outside of the car. You may need to apply some penetrating oil to help with rust, etc.
2. Holding the hood in place, drill the hinge and hood assembly with a 1/4" inch drill bit. Again, from the inside out.
3. You're now ready to push the quick release pin into place and lock the safety bail over the end of the pin.

99-4185/0305