

EMPI Header part number:

3100 3102

3103 3104



EMPI Muffler part number:

3200 3201

3202 3204

3205 3120 3122

Due to the size of the pipe needed to get the maximum performance from this muffler and header system, the tolerances for fit when attaching the muffler are very close. The bottom bolt should be installed from the header side of the flange.

Place the nut over the hole of the muffler, then thread the bolt into the nut. You should start all 3 nuts and bolts before tightening the entire assembly.

