

## Instructions for Installing Emblems

1. Remove Emblem and the three speed nuts from poly bag and carefully place the emblem on the outside of hubcap through the three holes.
2. Flip over the hubcap and emblem and place on a flat protected surface to avoid scratching the chrome surface or damaging the emblem.
3. Place the 3 speed nuts on the emblem studs by hand, then using a small box wrench or a small socket gently press the speed nuts down as far as they will go.
4. Repeat this process on the remaining Emblems and hubcaps.