

Instructions for Vintage Exhaust Tip Installation for Part# 00-3363-0

1. Place 1/4-20 x1" Stainless steel Bolt thru the clamp and place one nut on the bolt.
2. Insert Tip over existing OEM design tips and determine suitable distance that the tip protrudes out of the rear skirt.
3. Tighten Bolt and nut to secure the new tip to the existing tip, when clamp is tightened sufficiently (tip cannot rotate or slide on existing tip) install the 2nd nut to prevent nut from loosening up (double nut).
4. Repeat process for the other tip.

99-4445-0/0717