



Item # 99-4150-0

Instruction Sheet for JayCee Push Rod Tubes

1. Install the 16 O-rings on the short tube grooves.
2. Install the 8 springs gently over the O-rings.
3. Lubricate the inside long tubes and O-rings with motor oil.
4. Install chamfer side of long tube to short o-ringed tube.
5. Cycle tubes compressing together for a smooth action.
6. Install one backing washer on the end of each long tube.
7. Install the provided VW seals on the end of each tube.
8. Make sure the case and head sealing surface are clean.
9. Using silicone, adhere a thin coat on the case and tubes.
10. Compress short end to case enough for long tube to seat on head.
11. Inspect closely for seals to be seated correctly.
12. Assemble valve train and adjust valves.
13. Rotate valve train to assure your pushrods do not interfere with tubes.
14. Thank you for taking Pride in your Ride and enjoy your high-quality leak-proof push rod tubes.