## 16-2531 Race Trim Hydraulic Pedal Assembly

When installing your pedal assembly you may chose to install a shaft pin to stop the shaft from rotating within the Pedal Base.

- 1. Determine desired position of Throttle Pedal
- 2. Drill a 3/16" hole thru shaft using the pre-drilled holes in the Pedal Base as a fixture
- 3. Press/Tap the Shaft Pin (attached) thru the Pedal Base and Pedal Shaft

