

INSTALLATION INSTRUCTIONS

DO NOT REMOVE ALL OLD WIRES AT ONCE
REMOVE AND REPLACE ONE AT A TIME

1. Remove longest spark plug cable first from car.
2. Select longest new wire from set.
3. Install wire at distributor.
4. The other end is snapped on the spark plug after the threaded end provided is installed.
5. Repeat above steps with each cable going from the longest first to the shortest wire last.
6. Install coil wire in distributor. Measure wire to coil and cut to length. Slide nipple on wire. Now press brass clip firmly into the end of wire and crimp. This end is now ready to snap into coil.

99-4377-0/0515