

47-7412 KIT

We have included a 160 Main Fuel Jet and a 180 Air Jet.

Remove carburetor top and remove the Main Fuel jet

and replace with the 160 Main Fuel Jet (bottom of float bowl).

Remove the Main Air Jet (Upper most jet in carburetor)

and replace with the 180 Main Air Jet.