17-2880 Narrow Oil Sump Instructions

PREPARE THE ENGINE BY DRAINING THE OIL AND REMOVING THE STOCK OIL SUMP PLATE

- 1. Clean the sump and all the parts thoroughly. Any foreign material in the oil sump may cause engine damage.
- 2. Chose the oil pickup extension that fits your engine (see figure 1). You will need to cut 11/4" off the tip of the extension (see figure 2).
- 3. Secure the extender tube to the oil pickup with the hose clamp provided in this kit (see figure 3).
- 4. Install one gasket and align the sump over the studs on the engine case. Use the nuts and washers supplied to secure the sump to the engine case.
- 5. Install the gasket to the bottom of the sump and secure the sump cover in place using the nuts and washers.







Figure 1 Figure 2

Figure 3